

IMHOF



*Arthur*

User guide

The Imhof spirit never wavers in its pursuit of excellence, continuously exploring new realms of creativity, while honoring the remarkable talents of all those who have shaped the brand's past.



All you need to know about the guarantee of your watch

## International *guarantee*

Starting on the date of purchase entered on this certificate, a five-year international guarantee covers Imhof watches against manufacturing defects that affect the proper functioning of the watch itself (movement, case, dial, hands, crown, push-button and crystal).

During the warranty period and upon presentation of the valid warranty certificate, you are entitled to have any defect repaired free of charge. If your Imhof watch cannot be repaired to normal operating conditions, Imhof will

replace it with an identical Imhof watch or one with similar characteristics.

To obtain a replacement or repair under the guarantee, please use the contact form provided on our website [www.imhofwatches.com](http://www.imhofwatches.com) or write to us at the following postal address:

### **Monjour Watch Group SA**

(IMHOF brand)

Zentralstrasse 46

Postfach 1130

2502 Biel

Switzerland



# Usual guarantee *limits*

Any repairs we may need to carry out as a result of the following will be invoiced in all cases (following your signed acceptance of the quotation), including during the guarantee period.

Observed damage arising from incorrect use or serious negligence (major impacts, crushing, broken crystal) or any damage arising from unjustifiable modifications or repairs.

# Observe damage *from fire, acid or natural disasters*

Damage resulting from prolonged exposure to extreme conditions (such as temperatures above 60°C or below -10°C) will be observed.

Aesthetic changes due to wear and tear or normal aging (such as minor scratches on the case or glass, or changes in the color of the case or strap) are not included in this warranty.

The warranty may not be honored if the point of sale and date of purchase are unclear, illegible, or have been altered on the guarantee certificate, or if the

guarantee certificate is not provided with the watch.

Any component of the watch, including the case, crown, push-button, hands, dial, glass, strap, buckle, the complete movement, or any part thereof, may be replaced with substitute components if the original parts are no longer available.



Imhof timepieces,  
emblems of Swiss quality.

# Water resistance *to 100 m (10 atm)*

The entire Arthur collection is water-resistant to a depth of 100 meters, meaning they can withstand pressure equivalent to immersion in water up to 10 ATM.

When using the watch in a wet environment, always ensure that the winding crown is in its original position (manual winding position, 01) to maintain effective water resistance.

## **Recommended Maintenance Schedule :**

It is advisable to have your watch, at least, inspected regularly by a qualified watchmaker or an authorized after-sales service center.

Ideally, the water resistance should be checked every two years, and the overall operation and functions every five years.



# Movement

Mechanical movement with automatic winding by a ball-bearing-mounted central oscillating rotor



Height	4.60 mm
Case fitting diameter	30,40 mm (13 ¼)
Balance-wheel frequency	28'800 vibrations per hour (4 Hz)
Number of jewels	26
Angle lift of balance	50°
Power reserve	41 hours
Regulating organ (escapement)	«Top» chronometer quality
Pallet fork	Polie
Balance fork	Gilt
Max. divergence all positions	COSC criteria





# Functions



## The crown has three positions

1. Neutral position
2. Date-correction position
3. Time-setting position

## Important note

When in the time-setting position, do not turn the crown downwards.  
It is indispensable to set the watch to time before making the date correction.

## Starting the watch

Crown in position 1. This position enables you to restart the self-winding movement manually by turning the crown upwards.

## Important note

Important note: Once the time-setting is complete, the date correction must not under any circumstances be done while the watch shows the time between 11 pm and 4 am.

## Correcting the date

Pull the crown out to position 2.  
Turn the crown downwards until the required date (D).

## Important note

To restore your crown to its watertight position, you need to press on the crown while screwing it in.  
We advise you to check that it is firmly in place before use.

## Setting the time

Pull the crown out to position 3. Turn the crown upwards to move the hands (A,B,C) to the required time.  
For accurate time-setting, ensure that the last adjustment of the hands is made in a clockwise direction.  
After this operation, push the crown back to position 1.  
Turn the crown downwards to make sure it turns freely.

## Kindly remember


This watch is guaranteed water-resistant to 10 bar (100 meters), provided the crown is in position 1.

The bracelet features a patent-pending, fine-adjustment clasp system that allows the wearer to choose from six sizes without the need for any tools.



# Strap *adjustment*

The strap on Arthur watches can be adjusted without the need for tools.  
The IMHOF shield is a button you can press to adjust the strap to your wrist.



## First step

Press the IMHOF shield (A) to release the strap.

## Second step

Keep the button (A) depressed, and adjust your strap to the position you want (0 (B) to 6 (C)), there are 6 positions available so that your watch fits perfectly on your wrist.

## Third step

Release the button (A) to set your strap to the right position.



# IMHOF

**SWISS WATCHES**  
**1888**

Biel

Switzerland

© 2024 IMHOF

ALL RIGHTS RESERVED

[imhofwatches.com](https://imhofwatches.com)

